

0030103225

DJM-250 - FLIGHTBAG PIONEER DJM-250

The Zomo FlightBag DJM-250 is a great combination of DJ-Bag and Flightcase. It has been developed for the Pioneer DJM-250. A very sturdy metal frame provides sufficient protection for the mixer and ensures that the bag always stays in shape and guarantees a long service life. The foam inserts included in the delivery make it easy and safe to store even smaller mixers. Thanks to the integrated Velcro fasteners, the foam can be attached to the sides of the flight bag, ensuring a perfectly padded and safe transport of your mixer. The practical advantages of a bag such as a comfortable shoulder strap that can be adjusted in length or the additional outside pockets that offer plenty of space for all kinds of accessories (such as mobile phones, chargers, etc.) are perfectly combined with the stability of a flightcase. Zomo FlightBags are an optimal addition to your valuable equipment and always ensure a successful appearance. Your mixer is safely embedded in the Zomo FlightBag DJM-250 and protected from damage and scratches by the first-class interior cladding. ** The illustrated or mentioned devices are not included in delivery.



0030103225

DJM-250 - FLIGHTBAG PIONEER DJM-250

PRODUCT DETAILS

KEY FEATURES

High quality and soft interior stuffing with a robust metal frame

Protects against instances of damage

Comfortable handle

Replaceable shoulder belt to carry

Durable and waterproof material

Capacity: Pioneer DJM-250

Material: Nylon 1680 D

Internal Dimensions (W x D x H): 420 x 260 x 68 mm

Weight: 2.00 kg