

0030103048

KAOSSPAD 3 - FLIGHTBAG KORG KAOSSPAD 3

The Zomo FlightBag Kaosspad 3 is a perfect combination of DJ-Bag and Flightcase. The FlightBag is specifically matched on different Controllers and provides excellent protection and serves generous features for your equipment. Thanks to the included and suitable foam inserts it's also possible to transport smaller Controllers safely and easily. The integrated hook-and-pile fastener on the sides of the foam material provides a perfect fitting and secure hold and ensure an ideally cushioned transport of your controllers. The Zomo FlightBag Kaosspad 3 has a very solid metal frame that keeps the DJ bag's shape. This is the guarantee for a long life of DJ FlightBags. Moreover, your Controllers are well protected. This stability of a DJ Flightcase is perfectly combined with the practical advantages of a DJ Bag, like a comfortable shoulder belt which is adjustable in length or the convenient outside compartment that offers plenty of space for any kind of accessories (like cell phones, power supplies, cables, etc.) and small items. The Zomo FlightBag Kaosspad 3 is an ideal completion to your valuable equipment and always ensures an imposing entrance. The Controllers are embedded securely and protected from damage and scratches by the first-class interior stuffing. Sheer genius and totally cool! It's Zomo!



0030103048

KAOSSPAD 3 - FLIGHTBAG KORG KAOSSPAD 3

PRODUCT DETAILS

KEY FEATURES

High quality and soft interior stuffing with a robust metal frame

Protects against instances of damage

Comfortable handle

Replaceable shoulder belt to carry

Durable and waterproof material

SPECIFICATIONS

Material	Nylon 1680 D - 100% Nylon
Internal dimensions	330 x 195 x 58 mm
Weight	1.40 kg

** The illustrated or mentioned devices are not included in delivery. They are available in our shop.