

0030102986

DDJ-SX - FLIGHTBAG PIONEER DDJ-SX

The Pioneer DDJ-SX MIDI DJ Controller specifically matches to the Zomo FlightBag DDJ-SX, which provides excellent protection and serves generous features for your equipment. This perfect combination of DJ-Bag and Flightcase has practical advantages like a comfortable shoulder belt which is adjustable in length or the convenient outside compartments that offer plenty of space for any kind of accessories and small items. These advantages are perfectly combined with the stability of a DJ Flightcase. A very solid metal frame keeps the DJ bags shape. This is the guarantee for a long life of DJ FlightBags. Moreover, the Pioneer DDJ-SX DJ Controller is well protected. Zomo FlightBags are an ideal completion to your valuable equipment and always ensure an imposing appearance. The additional pocket for the laptop and three outside pockets provide plenty of extra storage space for cables, CDs, external sound cards or other accessories. The Zomo FlightBag DDJ-SX for the Pioneer DJ Controller is embedded securely and protected by the first-class interior stuffing from damage and scratches. Sheer genius and totally cool! It's Zomo!



0030102986

DDJ-SX - FLIGHTBAG PIONEER DDJ-SX

PRODUCT DETAILS

KEY FEATURES

Strong internal padding, sturdy metal frame

Protects the device from harmful influences

Comfortable, removable shoulder belt (Zomo Shoulder Belt CS black)

Padded carrying handle

Durable black, waterproof material

SPECIFICATIONS

Material	Nylon 1680 D - 100% Nylon
Dimensions (LxWxH)	760 x 405 x 125 mm
Weight	2.88 kg

** The illustrated or mentioned devices are not included in delivery.