




DD630S

## **ELECTRONIC DRUM SET COMPACT AND ELEGANT WITH 10" 2 ZONE MESH SNARE AND EXPANDIBILITY TO 2 CRASH AND 4 TOM**

The Medeli DD630S is a digital drum complete with everything! The newly designed and intuitive audio module features a backlit LCD display and contains 408 different drum sounds distributed over 30 factory programmed kits, as well as 10 user drum kits, where you can create and save your own Drum set. There are also 80 training presets, as well as a metronome with adjustable speed (30-280 bpm). The drum kit includes a 10" two-zone MESH Snare Pad and is equipped with sturdy attachments and easy to adjust and assemble. There is also the possibility of integrating another dish. The kit has a MIDI output, as well as a USB port for connecting to a computer or other external devices.

DD630S

0909b9a5-987b-41f5-9079-e191482ca273.jpgf3ac9521-8528-4ff0-b0d2-e732f08739de.jpg8d045a76-cd08-4cd8-af38-d470dbb

DD630S

# ELECTRONIC DRUM SET COMPACT AND ELEGANT WITH 10" 2 ZONE MESH SNARE AND EXPANDIBILITY TO 2 CRASH AND 4 TOM

## PRODUCT DETAILS

### KEY FEATURES

Backlit LCD Display

30 Drum kits, 408 Sounds, 10 Hi-Hat Combination, 60 preset songs and 10 User Song.

10" Two-zone MESH Snare Pad

Three coach modes with dozens of common best practice. Automatically score function intuitively reflects practice condition.

AUX IN input to connect external devices such as smartphones, tablets or CD Player and play along with your favorite songs.

Headphone Input for quiet practicing.

USB Port to connect to Computer using MIDI protocol to connect with several software.

Stereo output (R, L/MONO) for the connection to an external audio system or to a drum amplifier/Monitor.

Connection to add the 2nd Crash and the 4th Tom.

DC 9V/500mA Power Supply with AC/DC Adapter included.

### SPECIFICATIONS

|                      |                                                                                                                                                |
|----------------------|------------------------------------------------------------------------------------------------------------------------------------------------|
| Display              | Backlit LCD.                                                                                                                                   |
| Polyphony            | 64                                                                                                                                             |
| Drum Pads and Pedals | 1 two-zone MESH Snare pad, 3 Tom pad , 1 Crash with Choke, 1 Ride with Choke, 1 Hi-hat (continuous control), Hi-hat Pedal, Kick pad and pedal. |
| Controls             | Power on/off, Master Volume, Click, Kit/ Voice, Save/ Enter, Drum Off, DBT, Coach, Song/ Rec, Start/Stop, Utility, Tempo, +/-, Page, Dial.     |
| Connection           | TRIGGER INPUT Connector(DB25), PHONES, LINE OUT(R, L/MONO), TOM4, CRASH2, MIDI OUT, AUX IN, USB-MIDI.                                          |

DD630S

# ELECTRONIC DRUM SET COMPACT AND ELEGANT WITH 10" 2 ZONE MESH SNARE AND EXPANDIBILITY TO 2 CRASH AND 4 TOM

|                            |                                                                              |
|----------------------------|------------------------------------------------------------------------------|
| Sequencer                  | 5 User song with Real-time Recording til 25000 notes and 192 ticks per beat. |
| Tempo                      | 30~280                                                                       |
| Metronome                  | Click voice; Volume; Time signature; Interval select.                        |
| Trigger Parameters         | Sensitivity; Curve; Crosstalk; Retrigger cancel.                             |
| Power Supply               | DC 9V/500mA (AC/DC Adapter Included)                                         |
| Dimensions (WxDxH)         | 1140 x 610 x 1200 mm                                                         |
| Weight                     | 17,4 kg                                                                      |
| Packing Dimensions (WxDxH) | 880 x 580 x 335 mm                                                           |
| Packing Weight             | 23Kg                                                                         |