

7706500000

2-BUTTON FOOTSWITCH ACOUSTIC PRO/SFX® BLACK

Restore your contemporary Fender® amp's footswitch functionality with a genuine replacement Fender footswitch.

7706500000

[6acb95d7-2cf8-4ae8-8429-f7c8629c7b4e.jpg](#)

[14106daf-7746-4bb3-a7ba-14c33af7950b.jpg](#)

PRODUCT DETAILS

KEY FEATURES

12' cable with 1/4" plugs

Used for Acoustic Pro and Acoustic SFX® amplifiers

Connection Type: 1/4"

Style: Modern