

### 0030103257

# **DDJ-SB3 - FLIGHTBAG PIONEER DDJ-SB3**

Specially designed for the DDJ-SB3, the Zomo Flightbag offers optimum protection and generous equipment. The successful combination of DJ bag and flightcase offers you practical advantages such as a comfortable shoulder strap that can be adjusted in length or the practical outer pockets that offer plenty of space for all kinds of accessories (such as mobile phones, chargers, etc.) but also the stability of a flightcase. The DDJ-SB3 DJ controller has a very sturdy metal frame that protects the Pioneer DDJ-SB3 DJ controller and ensures that the case always stays in shape and guarantees a long service life. Zomo FlightBags are an optimal addition to your valuable equipment and always ensure a successful appearance. The Pioneer DJ-Controller is embedded in the Zomo FlightBag DDJ-SB3 and is protected from damage and scratches by the first-class interior cladding. The additional compartment for the laptop and three additional outside pockets provide plenty of extra storage space for cables, CDs, external sound cards or other accessories.



# **PRODUCT DETAILS**

#### **KEY FEATURES**

Strong inner padding, sturdy metal frame

Protects the device from harmful effects

Comfortable, detachable shoulder strap (Zomo replacement shoulder strap CS black)

Padded carrying handle

Resistant black, water-repellent black fabric

## **SPECIFICATIONS**

Material	100% Nylon - 1680 D
Dimensions	50.5 cm x 32.5 cm x 7 cm
Weight	2,45 kg

