

0030102993

## MIXDECK EXPRESS - FLIGHTBAG NUMARK MIXDECK EXPRESS

The Numark Mixdeck Express MIDI DJ Controller specifically matches to the Zomo FlightBag Mixdeck Express, which provides excellent protection and serves generous features for your equipment. The perfect combination of DJ-Bag and Flightcase has practical advantages like a comfortable shoulder belt which is adjustable in length or the convenient outside compartments that offer plenty of space for any kind of accessories and small items. These advantages are perfectly combined with the stability of a DJ Flightcase. A very solid metal frame keeps the DJ bags shape. This is the guarantee for a long life of DJ FlightBags. Moreover, the Numark Mixdeck Express DJ Controller is well protected. Zomo FlightBags are an ideal completion to your valuable equipment and always ensure an imposing appearance. The additional pocket for the laptop and three outside pockets provide plenty of extra storage space for cables, CDs, external sound cards or other accessories. The Zomo FlightBag Mixdeck Express for the Numark DJ Controller is embedded securely and protected by the first-class interior stuffing from damage and scratches. Sheer genius and totally cool! It's Zomo! \*\* The illustrated or mentioned devices are not included in delivery!



0030102993

# MIXDECK EXPRESS - FLIGHTBAG NUMARK MIXDECK EXPRESS

## PRODUCT DETAILS

### KEY FEATURES

Strong internal padding, sturdy metal frame

Protects the device from harmful influences

Comfortable, removable shoulder belt (Zomo Shoulder Belt CS black)

Padded carrying handle

Durable black, waterproof material

Capacity: 1 x Numark Mixdeck Express + 1 x Notebook

Material: Nylon 1680 D - 100% Nylon

Dimensions (LxWxD): 760 x 405 x 125 mm

Weight: 2.88 kg