

STUDIO MICROPHONE POP SCREEN

PS1 is a pop filter used for reducing wind noise during close vocal reproduction in studio apps. You can mount it by clipping to your mic stand . Universal clip mount system for all kind of mic stands.



PRODUCT DETAILS

KEY FEATURES

Isolate microphone from moisture

Universal clipping mount for every mic stand

